VERIFICATION

STATE OF OHIO)	
)	SS:
COUNTY OF HAMILTON)	

The undersigned, Bradley A. Seiter, Sr. Project Manager, being duly sworn, deposes and says that he has personal knowledge of the matters set forth in the foregoing data requests, and that they are true and correct to the best of his knowledge, information, and belief.

Bradley A. Seiter Affiant

Subscribed and sworn to before me by Bradley A. Seiter on this 15th day of 1000 , 2022.

NOTAKI I ODDIG

My Commission Expires: Joy 8, 2027

EMILIE SUNDERMAN Notary Public State of Ohio My Comm. Expires July 8, 2027

<u>VERIFICATION</u>

STATE OF NORTH CAROLINA)	
)	SS
COUNTY OF MECKLENBURG)	

The undersigned, Brian Weisker, Sr. Vice President, Chief Operating Officer Natural Gas, being duly sworn, deposes and says that he has personal knowledge of the matters set forth in the foregoing data requests, and that they are true and correct to the best of his knowledge, information, and belief.

Brian Weisker Affiant

Subscribed and sworn to before me by Brian Weisker on this day of

SHANNON L. WALL Notary Public, North Carolina Mecklenburg County My Commission Expires June 28, 2027

NOTARY PUBILIC

My Commission Expires:

6/28/2027

KyPSC Case No. 2022-00084 TABLE OF CONTENTS

DATA REQUEST	WITNESS	TAB NO
STAFF-DR-04-001	Brian Weisker	1
STAFF-DR-04-002	Brian Weisker	2
STAFF-DR-04-003	Brad Seiter	3

Duke Energy Kentucky Case No. 2022-00084

STAFF Fourth Set Data Requests

Date Received: October 26, 2022

STAFF-DR-04-001

REQUEST:

Refer to the testimony of Brian R. Weisker, pages 4-5, lines 11-21, 1-5, State verbatim and

cite any language in CFR Part 192 that requires replacement or retrofitting of existing

pipeline to accommodate an in-line inspection (ILI) tool.

RESPONSE:

Subpart O of CFR Part 192 states that the appropriate methods must be used to assess

threats that are active on covered pipeline segments. AM07 contains segments of A.O.

Smith pipe with active manufacturing, construction, and Low Frequency Electric Reistence

Weld (LF-ERW) threats that can only be assessed via ILI or pressure test. A.O. Smith pipe

is known to have hard spots (manufacturing defect) that can lead to failure if not inspected

with the appropriate ILI tool. These hard spots on A.O. Smith pipe of similar vintage as

that contained in line AM07 were documented in the final NTSB report NTSB/PIR-22/02

as one of the causes of the 2019 Danville Kentucky Enbridge pipeline rupture.

The active threats contained on AM07 must be assessed via ILI or pressure test at

a maximum of every 7 years.

Duke Energy believes that the safest and most cost-effective path forward is to

replace the current pipeline with a new line that is ILI capable.

§ 192.921 How is the baseline assessment to be conducted?

- (a) Assessment methods. An operator must assess the integrity of the line pipe in each covered segment by applying one or more of the following methods for each threat to which the covered segment is susceptible. An operator must select the method or methods best suited to address the threats identified to the covered segment (See § 192.917).
 - (1) Internal inspection tool or tools capable of detecting those threats to which the pipeline is susceptible. The use of internal inspection tools is appropriate for threats such as corrosion, deformation and mechanical damage (including dents, gouges and grooves), material cracking and cracklike defects (*e.g.*, stress corrosion cracking, selective seam weld corrosion, environmentally assisted cracking, and girth weld cracks), hard spots with cracking, and any other threats to which the covered segment is susceptible. When performing an assessment using an in-line inspection tool, an operator must comply with § 192.493. In addition, an operator must analyze and account for uncertainties in reported results (*e.g.*, tool tolerance, detection threshold, probability of detection, probability of identification, sizing accuracy, conservative anomaly interaction criteria, location accuracy, anomaly findings, and unity chart plots or equivalent for determining uncertainties and verifying actual tool performance) in identifying and characterizing anomalies;
 - (2) Pressure test conducted in accordance with <u>subpart J of this part</u>. The use of subpart J pressure testing is appropriate for threats such as internal corrosion; external corrosion and other environmentally assisted corrosion mechanisms; manufacturing and related defects threats, including defective pipe and pipe seams; stress corrosion cracking; selective seam weld corrosion; dents; and other forms of mechanical damage. An operator must use the test pressures specified in Table 3 of section 5 of ASME/ANSI B31.8S (incorporated by reference, *see* § 192.7) to justify an extended reassessment interval in accordance with § 192.939.
 - (3) Spike hydrostatic pressure test conducted in accordance with § 192.506. The use of spike hydrostatic pressure testing is appropriate for time-dependent threats such as stress corrosion cracking; selective seam weld corrosion; manufacturing and related defects, including defective pipe and pipe seams; and other forms of defect or damage involving cracks or cracklike defects;

§ 192.939 What are the required reassessment intervals?

An operator must comply with the following requirements in establishing the reassessment interval for the operator's covered pipeline segments.

- (a) *Pipelines operating at or above 30% SMYS*. An operator must establish a reassessment interval for each covered segment operating at or above 30% SMYS in accordance with the requirements of this section. The maximum reassessment interval by an allowable reassessment method is 7 calendar years. Operators may request a 6-month extension of the 7-calendar-year reassessment interval if the operator submits written notice to OPS, in accordance with § 192.18, with sufficient justification of the need for the extension. If an operator establishes a reassessment interval that is greater than 7 calendar years, the operator must, within the 7-calendar-year period, conduct a confirmatory direct assessment on the covered segment, and then conduct the follow-up reassessment at the interval the operator has established. A reassessment carried out using confirmatory direct assessment must be done in accordance with § 192.931. The table that follows this section sets forth the maximum allowed reassessment intervals.
 - (1) *Pressure test or internal inspection or other equivalent technology.* An operator that uses pressure testing or internal inspection as an assessment method must establish the reassessment interval for a covered pipeline segment by -
 - (i) Basing the interval on the identified threats for the covered segment (see § 192.917) and on the analysis of the results from the last integrity assessment and from the data integration and risk assessment required by § 192.917; or
 - (ii) Using the intervals specified for different stress levels of pipeline (operating at or above 30% SMYS) listed in ASME B31.8S (incorporated by reference, *see* § 192.7), section 5, Table 3.

PERSON RESPONSIBLE: Brian R. Weisker

Duke Energy Kentucky Case No. 2022-00084

STAFF Fourth Set Data Requests

Date Received: October 26, 2022

STAFF-DR-04-002

REQUEST:

Refer to Duke Kentucky's response to Commission Staff's Third Request for Information

(Staff's Third Request), Item 1(c). State whether pressure testing without retrofitting for

use of an ILI tool would result in excavation or replacement work.

RESPONSE:

Excavation work would be required in order to separate the sections of pipe being tested

from the remainder of the mainline and regulating stations that must be left in service. In

addition, pipeline features that would prevent the passage of cleaning and drying pigs

would need to be replaced in order for the pressure test to be conducted. Any failures that

may occur during pressure testing would need to be excavated and repaired.

PERSON RESPONSIBLE:

Brian R. Weisker

Duke Energy Kentucky Case No. 2022-00084

STAFF Fourth Set Data Requests

Date Received: October 26, 2022

STAFF-DR-04-003

REQUEST:

Refer to Duke Kentucky's response to Staff's Third Request, Item 1(a).

a. State the estimated cost of pressure testing the existing AM07 pipeline without

retrofitting for use of an ILI tool. Itemize these costs by costs of testing, bypassing,

temporary gas supply, excavation, and correcting deficiencies found during testing.

b. Provide any documentation or other information used to determine the estimated

cost stated in response to Item 3(a) above.

c. Provide a cost-benefit analysis of the proposed pipeline replacement, including

capital cost, depreciation, and future testing costs for the life of the new pipeline

and a cost-benefit analysis of pressure testing existing pipeline without retrofitting

for use of an ILI tool for the same period in time.

RESPONSE:

a. The cost to pressure test the first phase of the AM07 pipeline would be

approximately \$15 million. Temporary gas would make up at least \$5 million of

that with the remaining being budgeted for engineering, material, excavation, and

labor. Correction of deficiencies discovered during a pressure test would be

consider retrofitting the line and therefore is not included in the estimate for

hydrotesting the line. In addition, any deficiencies identified will extend the use of

temporary gas, and those costs are not included in the estimate.

b. Please refer to STAFF-DR-04-003(b) Attachment for cost estimate breakdown.

c. Objection. This request is unreasonable and overly broad and unduly burdensome and calls for speculation. The Company has not performed the analysis in the format requested and has not conducted a depreciation study for the entire AM07 project, which is a multi-year phase in construction. Without waiving said objection, and to the extent discoverable, the Company submits that the estimated costs of the first phase AM07 replacement project are \$32.25 million as noted in STAFF-DR-02-001(c). This project estimate was provided to address the replacement of the first phase of AM07. The need for the project was explained in the Company's Application and is due to the now known risk of failure of the type of pipe used in the construction of the initial AM07 decades ago. An initial In-Line Inspection will occur 10 years after installation of the pipeline, with on-going inspections occurring every 7 years thereafter. Approximate costs to perform an In-Line Inspection on AM07 phase 1 is \$300,000.

The estimated cost of hydro pressure testing phase 1 of the existing pipeline without retrofitting for use of an ILI is approximately \$15 million as noted in response to (a). As noted, this does not include any costs to repair deficiencies identified while performing the hydrotest. Thus, additional costs to repair discovered deficiencies would be incremental, and would take the line out of service for additional time and an unknown incremental cost along with risks to the system and customer reliability to continue natural gas service if the repairs could not be accomplished in sufficient time to put the line back in service for winter heating seasons. Additionally, A hydrotest of AM07 Phase I pipeline would be required on a 7-year cycle at an approximate cost of \$15 million (not including inflation) each time the hydrotest is performed.

In addition to significantly reducing the 7-year cycle assessment costs, In-

Line Inspections will provide data to fully understand the integrity of the pipeline

and physical condition of the pipeline that cannot be determined from a pressure

test. Replacement of AM07 provides the customer with a safer, cost effective solution.

PERSON RESPONSIBLE:

Bradley A. Seiter

Line AM07 Re-Hydro Kentucky **Project Cost Breakdown** Class 5 Revision: A **Capital Improvement** Retirement **Capital Improvement** Size / Name and Retirement Length / Qty **WBS 1** Description Total Phase 1 Only Pipe Abandon 1 108,200 108,200 NGENGNC Engineering 116,300 8,100 NGLANDC Land - Permanent NGLANDC Land - Temporary 84,300 84,300 84,300 40,000 40,000 NGLANDC Land - Support 40,000 NGLANDC Land Legal NGMATEC Materials/Equipment 246,500 234,500 234,500 12,000 NGCONPC Construction Serv - Pipeline 10,012,000 9,970,500 9,970,500 41,500 NGCONFC Construction Serv - Facility NGFITSC 604,600 598,300 598,300 6,300 Field Inspections 10,000 10,000 NGFITSC Field Testing 10,000 NGMPGL Duke Labor 238,000 174,000 174,000 64,000 NGMOTH Other Direct Costs 60,000 16,000 44,000 44,000 **Subtotal Direct Cost** 11,411,700 11,263,800 11,263,800 147,900 Project Contingency 1,730,900 1,689,600 1,689,600 41,300 Project Escalation **Total Contingency & Escalation** 1,730,900 1,689,600 1,689,600 41,300 **Total Direct Cost** 13,142,600 12,953,400 \$ 12,953,400 189,200 NGMAFD AFUDC Debt 276,400 \$ 276,400 \$ 276,400 NGMOVH Overhead and Allocations 1,564,300 52,900 1.511.400 1,511,400 **Total PNG Overhead Cost** 1,787,800 1,787,800 52,900 **Project Total** 14,983,300 14,741,200 14,741,200 242,100

- Notes:

 1. Contingency is not included on escalation.
 - 2. Overheads and Allocations calculated using 12% of Total Direct Cost less Land Purchase, Materials/Equipment and FERC cost.
 - 3. AFUDC calculated using 3.69% of total Direct Cost. (No AFUDC on Retirement Cost.)
 - 4. No Project Escalation is assumed.

	Line AM(Pir	0 <mark>7 Re-Hyc</mark> be NPS	iro				Revision # A	
Control Code	Component Description	Units	Unit of Measure	U	nit Cost	Sı	ub-totals	Totals
Internal Engine	ering & Construction Management							
G101	PNG Labor	40	Month	\$	4,350		174,000	
OTH001	Other Direct Cost	40	Month	\$	1,100	\$	44,000	
Sub-Total - Inte	ernal E&CM						\$	218,000
External Engine	Pering							
G801	Pre-Design Activities	8	Hour	\$	125	\$	1,033	
G802	Route Development	9	Hour	\$	125	\$	1,136	
G803	Project Managemenet	36	Hour	\$	125	\$	4,442	
G804	Records Research	2	Hour	\$	125	\$	207	
G805	Estimating & Scoping	6	Hour	\$	125	\$	723	
G806	Land Survey	93	Hour	\$	125	\$	11,569	
G807	Land Acquistion Support (Engineering)	38	Hour	\$	125	\$	4,751	
G808	Environmental Services & Permitting	33	Hour	\$	125	\$	4,132	
G809	Geotechnical Services	45	Hour	\$	125	\$	5,681	
G810 G811	Design - Pipeline	76 0	Hour Hour	\$	125 125	\$	9,503	
G811 G812	Design - Facility Cathodic Protection	2	Hour	\$	125	\$	207	
G813	Bid Package Development	14	Hour	\$	125	\$	1,756	
G814	Construction Support	107	Hour	\$	125	\$	13,428	
G815	As-Built Survey	347	Hour	\$	125	\$	43,383	
G815	Project Close-out	10	Hour	\$	125	\$	1,240	
G663	MAOP	1	Lump Sum	\$	5,000	\$	5,000	
Sub-Total - Ext	ernal Engineering						\$	108,200
Land Services								
G661	Transmission - Fee Purchase - Rural	0	Acre	\$	_	\$	-	
G661	Transmission - Fee Purchase - Kurai Transmission - Fee Purchase - Urban	0	Acre	\$	125,000	\$	-	
G662	Transmission - Permanent Easements - Rural	0	Acre	ς ς	123,000	\$	-	
G662	Transmission - Permanent Easements - Urban	0	Acre	\$	150.000	\$	-	
G662	Transmission - Stations Easements - Rural	0	Acre	\$	-	\$	-	
G662	Transmission - Stations Easements - Urban	0	Acre	\$	175,000	\$	-	
G663	Transmission - Temporary Easements - Rural	0	Acre	\$	-	\$	-	
G663	Transmission - Temporary Easements - Urban	1	Acre	\$	31,250	\$	31,300	
G662 PA	Transmission - Access Roads	4	Each	\$	10,000	\$	40,000	
G663	Transmission - Laydown Yard	0	Months	\$	4,200	\$	-	
G656	Transmission - Damages	4	Per Parcel	\$	3,250	\$	13,000	
G656	Transmission - Additional Damages	0	Acre	\$	-	\$	-	
G301	Contract Labor - Land Services	4	Per Parcel	\$	10,000	\$	40,000	
G301 Sub-Total - Lan	Contract Labor - Legal	0	Per Parcel	\$	20,000	\$	- s	124 200
Sub-Total - Lan	a Services						,	124,300
Construction Se	ervices - Pipeline	23760	Overall LF of Pipe in	nstall				
820	Mob/Demob	1	Lump Sum	\$	906,402	\$	906,402	
821	Clearing and Grubbing	0	acre	\$	-	\$	-	
821	Tree Cutting Only/No Grubbing	0	acre	\$	-	\$	-	
829	Conventional Upland Lay	20	Linear Foot Linear Foot	\$	579	\$	11,580	
829	Conventional Upland Lay (Residential) Conventional Wetland Lay	0				\$	-	
830 825	Conventional Wetland Lay			\$	-			
	Conventional Bore - Dirt	0	Linear Foot	\$	-	\$	-	
826	Conventional Bore - Dirt Conventional Bore - Rock	0	Linear Foot Linear Foot	\$	-	\$		
826 827	Conventional Bore - Rock		Linear Foot Linear Foot Linear Foot	\$	- - -	\$	-	
		0	Linear Foot Linear Foot Linear Foot Linear Foot	\$ \$ \$	- - - -	\$ \$ \$	- - -	
827	Conventional Bore - Rock Directional Drill – Dirt	0 0 0	Linear Foot Linear Foot Linear Foot	\$ \$ \$ \$	- - - - -	\$ \$ \$ \$		
827 828	Conventional Bore - Rock Directional Drill – Dirt Directional Drill – Rock	0 0 0 0	Linear Foot Linear Foot Linear Foot Linear Foot Linear Foot	\$ \$ \$ \$	- - - -	\$ \$ \$ \$	- - - -	
827 828 828	Conventional Bore - Rock Directional Drill – Dirt Directional Drill – Rock SCAR Guard Application	0 0 0 0	Linear Foot	\$ \$ \$ \$ \$	- - - -	\$ \$ \$ \$ \$		
827 828 828 822 822 822	Conventional Bore - Rock Directional Drill – Dirt Directional Drill – Rock SCAR Guard Application Rock Excavation – Blasting Rock Excavation – Mechanical Stopple Pit	0 0 0 0 0 0 0 0	Linear Foot Linear Foot Linear Foot Linear Foot Linear Foot Linear Foot Cunear Foot Cubic Yard Cubic Yard Each	\$ \$ \$ \$ \$ \$ \$ \$	- - - -	\$ \$ \$ \$ \$ \$		
827 828 828 822 822 822 829	Conventional Bore - Rock Directional Drill – Dirt Directional Drill – Rock SCAR Guard Application Rock Excavation – Blasting Rock Excavation – Mechanical Stopple Pit Padding – Job Site	0 0 0 0 0 0 0 0 0 0 4	Linear Foot Linear Foot Linear Foot Linear Foot Linear Foot Linear Foot Cubic Yard Cubic Yard Each Linear Foot	\$ \$ \$ \$ \$ \$ \$ \$	- - - - - -	\$ \$ \$ \$ \$ \$ \$ \$		
827 828 828 822 822 829 829	Conventional Bore - Rock Directional Drill – Dirt Directional Drill – Rock SCAR Guard Application Rock Excavation – Blasting Rock Excavation – Mechanical Stopple Pit Padding – Job Site Padding - Haul	0 0 0 0 0 0 0 0 0 0 4	Linear Foot Cubic Yard Cubic Yard Each Linear Foot Linear Foot	\$ \$ \$ \$ \$ \$ \$ \$	- - - - - - 54,139	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$		
827 828 828 822 822 829 829 829	Conventional Bore - Rock Directional Drill – Dirt Directional Drill – Rock SCAR Guard Application Rock Excavation – Blasting Rock Excavation – Mechanical Stopple Pit Padding – Job Site Padding - Haul Sand Padding over Existing Lines	0 0 0 0 0 0 0 0 0 0 0 0	Linear Foot Linear Foot Linear Foot Linear Foot Linear Foot Linear Foot Cubic Yard Cubic Yard Each Linear Foot Linear Foot Cubic Yard Cubic Yard Cubic Yard Cubic Yard Cubic Yard	\$ \$ \$ \$ \$ \$ \$ \$ \$	- - - - - -	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		
827 828 828 822 822 829 829 829 829 829	Conventional Bore - Rock Directional Drill - Dirt Directional Drill - Rock SCAR Guard Application Rock Excavation - Blasting Rock Excavation - Mechanical Stopple Pit Padding - Job Site Padding - Haul Sand Padding over Existing Lines Rock Shield	0 0 0 0 0 0 0 0 0 4 0 0	Linear Foot Cubic Yard Cubic Yard Each Linear Foot Linear Foot Cubic Yard Linear Foot Linear Foot Linear Foot Cubic Yard Linear Foot	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$	- - - - - - 54,139	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		
827 828 828 822 822 829 829 829 829 829 829	Conventional Bore - Rock Directional Drill – Dirt Directional Drill – Rock SCAR Guard Application Rock Excavation – Blasting Rock Excavation – Mechanical Stopple Pit Padding – Job Site Padding - Haul Sand Padding over Existing Lines Rock Shield Saddle Bag Weight	0 0 0 0 0 0 0 0 0 4 0 0 0	Linear Foot Cubic Yard Cubic Yard Each Linear Foot Linear Foot Linear Foot Linear Foot Cubic Yard Linear Foot	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$	- - - - - - 54,139	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		
827 828 828 822 822 829 829 829 829 829 829	Conventional Bore - Rock Directional Drill – Dirt Directional Drill – Rock SCAR Guard Application Rock Excavation – Blasting Rock Excavation – Mechanical Stopple Pit Padding – Job Site Padding - Haul Sand Padding over Existing Lines Rock Shield Saddle Bag Weight River Weight	0 0 0 0 0 0 0 0 0 4 4 0 0 0 0	Linear Foot Linear Foot Linear Foot Linear Foot Linear Foot Linear Foot Cubic Yard Cubic Yard Each Linear Foot Linear Foot Cubic Yard Each Linear Foot Linear Foot Linear Foot Linear Foot Linear Foot Each Each Each	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$	- - - - - - 54,139	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		
827 828 828 822 822 829 829 829 829 829 829	Conventional Bore - Rock Directional Drill – Dirt Directional Drill – Rock SCAR Guard Application Rock Excavation – Blasting Rock Excavation – Mechanical Stopple Pit Padding – Job Site Padding - Haul Sand Padding over Existing Lines Rock Shield Saddle Bag Weight River Weight Concrete Coating	0 0 0 0 0 0 0 0 0 4 0 0 0 0 0 0 0 0 0 0	Linear Foot Cubic Yard Cubic Yard Each Linear Foot Linear Foot Linear Foot Linear Foot Each Linear Foot Linear Foot Linear Foot Linear Foot Each Each Linear Foot	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$	- - - - - - 54,139	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		
827 828 828 822 822 829 829 829 829	Conventional Bore - Rock Directional Drill – Dirt Directional Drill – Rock SCAR Guard Application Rock Excavation – Blasting Rock Excavation – Mechanical Stopple Pit Padding – Job Site Padding - Haul Sand Padding over Existing Lines Rock Shield Saddle Bag Weight River Weight Concrete Coating Zinc Ribbon (AC Mitigation)	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Linear Foot Cubic Yard Cubic Yard Each Linear Foot Linear Foot Cubic Yard Each Linear Foot Cubic Yard Linear Foot	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$	- - - - - - 54,139	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		
827 828 828 822 822 829 829 829 829	Conventional Bore - Rock Directional Drill – Dirt Directional Drill – Rock SCAR Guard Application Rock Excavation – Blasting Rock Excavation – Mechanical Stopple Pit Padding – Job Site Padding - Job Site Padding over Existing Lines Rock Shield Saddle Bag Weight River Weight Concrete Coating Zinc Ribbon (AC Mitigation) Anode Bed	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Linear Foot Cubic Yard Cubic Yard Each Linear Foot Linear Foot Cubic Yard Each Linear Foot Cubic Yard Linear Foot Linear Foot Linear Foot Linear Foot Each Each Linear Foot	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$	- - - - - 54,139 - - - - -	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		
827 828 828 822 822 829 829 829 829 829 831 831 831 837	Conventional Bore - Rock Directional Drill - Dirt Directional Drill - Rock SCAR Guard Application Rock Excavation - Blasting Rock Excavation - Mechanical Stopple Pit Padding - Job Site Padding - Job Site Padding over Existing Lines Rock Shield Saddle Bag Weight River Weight Concrete Coating Zinc Ribbon (AC Mitigation) Anode Bed Temporary Clean-up / Temporary Stabilization	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Linear Foot Cubic Yard Cubic Yard Each Linear Foot Cubic Yard Linear Foot Linear Foot Cubic Yard Linear Foot Linear Foot Linear Foot Each Linear Foot	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$	- - - - - - 54,139 - - - - - - - - - -	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		
827 828 828 822 822 829 829 829 829 829 831 831 831 837 837	Conventional Bore - Rock Directional Drill - Dirt Directional Drill - Rock SCAR Guard Application Rock Excavation - Blasting Rock Excavation - Mechanical Stopple Pit Padding - Job Site Padding - Job Site Padding - Haul Sand Padding over Existing Lines Rock Shield Saddle Bag Weight River Weight Concrete Coating Zinc Ribbon (AC Mitigation) Anode Bed Temporary Clean-up / Temporary Stabilization Hydro Test 1	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Linear Foot Cubic Yard Cubic Yard Each Linear Foot Cubic Yard Linear Foot Linear Foot Linear Foot Each Linear Foot Each Linear Foot Each Linear Foot	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$	- - - - - 54,139 - - - - - - - - - - - - - - - - - - -	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		
827 828 828 822 822 829 829 829 829 822 831 831 831 837 837 837	Conventional Bore - Rock Directional Drill - Dirt Directional Drill - Rock SCAR Guard Application Rock Excavation - Blasting Rock Excavation - Mechanical Stopple Pit Padding - Job Site Padding - Haul Sand Padding over Existing Lines Rock Shield Saddle Bag Weight River Weight Concrete Coating Zinc Ribbon (AC Mitigation) Anode Bed Temporary Clean-up / Temporary Stabilization Hydro Test 1 Hydro Test 2	0 0 0 0 0 0 0 0 4 0 0 0 0 0 0 0 0 0 0 0	Linear Foot Cubic Yard Cubic Yard Each Linear Foot Cubic Yard Linear Foot Linear Foot Linear Foot Each Each Linear Foot	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		
827 828 828 822 822 829 829 829 829 829 831 831 831 837 837	Conventional Bore - Rock Directional Drill - Dirt Directional Drill - Rock SCAR Guard Application Rock Excavation - Blasting Rock Excavation - Mechanical Stopple Pit Padding - Job Site Padding - Job Site Padding - Haul Sand Padding over Existing Lines Rock Shield Saddle Bag Weight River Weight Concrete Coating Zinc Ribbon (AC Mitigation) Anode Bed Temporary Clean-up / Temporary Stabilization Hydro Test 1	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Linear Foot Cubic Yard Cubic Yard Each Linear Foot Cubic Yard Linear Foot Linear Foot Linear Foot Each Linear Foot Each Linear Foot Each Linear Foot	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$	- - - - - 54,139 - - - - - - - - - - - - - - - - - - -	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		
827 828 828 822 822 829 829 829 829	Conventional Bore - Rock Directional Drill - Dirt Directional Drill - Rock SCAR Guard Application Rock Excavation - Blasting Rock Excavation - Mechanical Stopple Pit Padding - Job Site Padding - Haul Sand Padding over Existing Lines Rock Shield Saddle Bag Weight River Weight Concrete Coating Zinc Ribbon (AC Mitigation) Anode Bed Temporary Clean-up / Temporary Stabilization Hydro Test 1 Hydro Test 2 Hydro Test 3	0 0 0 0 0 0 0 0 4 0 0 0 0 0 0 0 0 0 0 0	Linear Foot Cubic Yard Cubic Yard Each Linear Foot Each Each Linear Foot	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		
827 828 828 822 822 829 829 829 829 829 821 831 831 837 837 837 837 838 833	Conventional Bore - Rock Directional Drill - Dirt Directional Drill - Rock SCAR Guard Application Rock Excavation - Blasting Rock Excavation - Mechanical Stopple Pit Padding - Job Site Padding - Haul Sand Padding over Existing Lines Rock Shield Saddle Bag Weight River Weight Concrete Coating Zinc Ribbon (AC Mitigation) Anode Bed Temporary Clean-up / Temporary Stabilization Hydro Test 1 Hydro Test 2 Hydro Test 3 Hydro Test 4	0 0 0 0 0 0 0 0 0 4 0 0 0 0 0 0 0 0 0 0	Linear Foot Cubic Yard Cubic Yard Each Linear Foot Linear Foot Linear Foot Linear Foot Linear Foot Linear Foot Each Linear Foot	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		

834 834							
834	Commissioning 2	11880	Linear Foot	\$	5	\$ 59,400	
	Commissioning 3	0	Linear Foot	\$	5	\$ -	
834	Commissioning 4	0	Linear Foot	\$	5	\$ -	
834	Commissioning 5	0	Linear Foot	\$	5	\$ -	
837	Re-coating of Exposed Pipe (Hand Application)	0	Linear Foot	\$	-	\$ -	
	Re-coating of Exposed Pipe (Spray Application)	0		\$	-		
837			Linear Foot		-	\$ -	
837	Armor Plate	0	Linear Foot	\$	-	\$ -	
829	Daylight Existing Utilities (Pot Holing)	4	Lump Sum		00	\$ 6,000	
829	AirVac/Hydro Vac Excavation	0	Cubic Foot	\$	-	\$ -	
829	Pipe Rack Construction (Dirt/Sand Berm)	0	Lump Sum	\$	-	\$ -	
829	Transition Of Bevels	0	Each	\$	-	\$ -	
837	Test Station Installation	4	Each	-	000	\$ 4,000	
829	Temporary Stabilization	0	Linear Foot	\$,00	\$ -	
	• •				-		
630	Silt Fence (metal post & wire backing)	4	Lump Sum		00	\$ 30,000	
630	Conventional Silt Fence	0	Linear Foot	\$	-	\$ -	
630	Super Silt Fence (metal post & chainlink fence backii	0	Linear Foot	\$	-	\$ -	
630	Curlex Blanket with Staples (4 x 100)	0	Square Yard	\$	-	\$ -	
630	Curlex Double Net Blanket with Staples (4 x 100)	0	Square Yard	\$	-	\$ -	
630	Curlex Triple Net Blanket with Staples (4 x 100)	0	Square Yard	\$	-1	\$ -	
					_		
630	Curlex Premier Coconut Blanket with Staples (4 x 10	0	Square Yard	\$	-	\$ -	
630	Curlex Premier Straw/Coconut Blanket with Staples	0	Square Yard	\$	-	\$ -	
630	Hydroseeding Temporary Stabilization	0	Square Yard	\$	-	\$ -	
630	Hydroseeding Permanent Stabilization	0	Square Yard	\$	- 1	\$ -	
630	Rip Rap Placement	0	Ton	\$	- 1	\$ -	
630	Gravel Placement	0	Ton	\$	-	\$ -	
				•	_		
630	Geo Textile Fabric	0	Square Yard	\$	-	\$ -	
630	Safety Fence	600	linear ft	\$	8	\$ 4,800	
630	Culvert Pipe (CMP)	0	Inch Dia per LF	\$	-	\$ -	
630	Sack Breakers	0	Each	\$	-	\$ -	
630	Sediment Basin (excludes rock)	0	Each	\$	-	\$ -	
630	Trench Breaker (Plug)	0	Each	\$	-1	\$ -	
630	Foam Breakers	0	Each	\$	-	\$ -	
630	Construction (Timber) Mats	100	Linear Foot (Width)	\$ 7	700	\$ 70,000	
630	Laminated (Truck) Mats	0	Linear Foot (Width)	\$	-	\$ -	
630	Bentonite Trench Seals in Wetlands	0	Each	\$	-	\$ -	
630	Permanent Seeding (seed straw, and tack)	20000	Square Foot		.11	\$ 2,200	
					_		
630	Intermediate Seeding (seed straw, and tack)	0	Square Foot	Y	_	\$ -	
630	Dry Crossing (Flume or Dam/Pump Method)	0	Each	\$	-	\$ -	
630	Sod	0	SF	\$	-	\$ -	
630	Straw Wattle 9" x 10'	0	Each	\$	-	\$ -	
630	Sediment Log 8"	0	Each	\$	-	\$ -	
630	Sediment Log 10"	0	Each	\$	-	\$ -	
630	Sediment Log 12"	0	Each	\$	-1	\$ -	
	-				-		
630	Sediment Log 20"	0	Each	\$	-	\$ -	
630	Erosion Eel 10"	0	Each	\$	-	\$ -	
630	Erosion Eel 12"	0	Each	\$	-	\$ -	
630	Erosion Eel 14"				_	\$ -	
		0	l Each	S	- 1		
620		0	Each Each	\$	_		
630	Erosion Eel 20"	0	Each	\$	-1	\$ -	
630	Erosion Eel 20" Permanent Waterbar Installation	0 0	Each Each	\$	_	\$ - \$ -	
	Erosion Eel 20"	0 0 0	Each	\$ \$	- - -	\$ - \$ - \$ -	
630	Erosion Eel 20" Permanent Waterbar Installation	0 0	Each Each	\$	- - -	\$ - \$ -	
630 630	Erosion Eel 20" Permanent Waterbar Installation Temporary Waterbar Installation	0 0 0	Each Each Each	\$ \$ \$ \$	- - -	\$ - \$ - \$ -	
630 630 630 630	Erosion Eel 20" Permanent Waterbar Installation Temporary Waterbar Installation Filtration Sediment Bags 10' x 15' Dewater Structure	0 0 0 0	Each Each Each Each Lump Sum	\$ \$ \$ \$ \$ \$	- - -	\$ - \$ - \$ - \$ - \$ 10,000	
630 630 630 630 630	Erosion Eel 20" Permanent Waterbar Installation Temporary Waterbar Installation Filtration Sediment Bags 10' x 15' Dewater Structure Clear Water Diversion Pit	0 0 0 0 2	Each Each Each Each Lump Sum Lump Sum	\$ \$ \$ \$ \$ \$ \$	- - - - 000	\$ - \$ - \$ - \$ - \$ 10,000	
630 630 630 630 630 630	Erosion Eel 20" Permanent Waterbar Installation Temporary Waterbar Installation Filtration Sediment Bags 10' x 15' Dewater Structure Clear Water Diversion Pit Stabilized Construction Entrance 20'W x 50'L x 6"D	0 0 0 0 2 0	Each Each Each Each Lump Sum Lump Sum Lump Sum	\$ \$ \$ \$ \$ \$ \$ \$	- - -	\$ - \$ - \$ - \$ - \$ 10,000 \$ - \$ -	
630 630 630 630 630 630 630	Erosion Eel 20" Permanent Waterbar Installation Temporary Waterbar Installation Filtration Sediment Bags 10' x 15' Dewater Structure Clear Water Diversion Pit Stabilized Construction Entrance 20'W x 50'L x 6"D Well Points	0 0 0 0 2 0 0	Each Each Each Each Lump Sum Lump Sum Lump Sum Each	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$	- - - 000 - -	\$ - \$ - \$ - \$ 10,000 \$ - \$ -	
630 630 630 630 630 630 630 831 832	Erosion Eel 20" Permanent Waterbar Installation Temporary Waterbar Installation Filtration Sediment Bags 10' x 15' Dewater Structure Clear Water Diversion Pit Stabilized Construction Entrance 20'W x 50'L x 6"D Well Points Air Bridges	0 0 0 0 2 0 0 0	Each Each Each Lump Sum Lump Sum Lump Sum Each Each	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$	- - - - 000	\$ - \$ - \$ - \$ 10,000 \$ - \$ - \$ - \$ -	
630 630 630 630 630 630 630	Erosion Eel 20" Permanent Waterbar Installation Temporary Waterbar Installation Filtration Sediment Bags 10' x 15' Dewater Structure Clear Water Diversion Pit Stabilized Construction Entrance 20'W x 50'L x 6"D Well Points	0 0 0 0 2 0 0	Each Each Each Each Lump Sum Lump Sum Lump Sum Each	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$	- - - 000 - -	\$ - \$ - \$ - \$ 10,000 \$ - \$ - \$ - \$ -	
630 630 630 630 630 630 630 831 832	Erosion Eel 20" Permanent Waterbar Installation Temporary Waterbar Installation Filtration Sediment Bags 10' x 15' Dewater Structure Clear Water Diversion Pit Stabilized Construction Entrance 20'W x 50'L x 6"D Well Points Air Bridges	0 0 0 0 2 0 0 0	Each Each Each Lump Sum Lump Sum Lump Sum Each Each	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$	- - - 000 - -	\$ - \$ - \$ - \$ 10,000 \$ - \$ - \$ - \$ -	
630 630 630 630 630 630 630 831 832	Erosion Eel 20" Permanent Waterbar Installation Temporary Waterbar Installation Filtration Sediment Bags 10' x 15' Dewater Structure Clear Water Diversion Pit Stabilized Construction Entrance 20'W x 50'L x 6"D Well Points Air Bridges Chain Link Fence & Gates – New Chain Link Fence & Gates – Repair	0 0 0 0 2 0 0 0 0	Each Each Each Lump Sum Lump Sum Lump Sum Lump Sum Lump Sum Lump Sum Each Each Linear Foot	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$	- - - 000 - - - -	\$ - \$ - \$ - \$ 10,000 \$ - \$ - \$ - \$ - \$ -	
630 630 630 630 630 630 831 832 832 832	Erosion Eel 20" Permanent Waterbar Installation Temporary Waterbar Installation Filtration Sediment Bags 10' x 15' Dewater Structure Clear Water Diversion Pit Stabilized Construction Entrance 20'W x 50'L x 6"D Well Points Air Bridges Chain Link Fence & Gates – New Chain Link Fence & Gates – Repair Temporary Pasture Fencing	0 0 0 0 2 0 0 0 0 0	Each Each Each Lump Sum Lump Sum Lump Sum Lump Fach Each Each Linear Foot Linear Foot	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$	- - - 000 - - - -	\$ - \$ - \$ - \$ 10,000 \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ -	
630 630 630 630 630 630 831 832 832 832 832 832	Erosion Eel 20" Permanent Waterbar Installation Temporary Waterbar Installation Filtration Sediment Bags 10' x 15' Dewater Structure Clear Water Diversion Pit Stabilized Construction Entrance 20'W x 50'L x 6"D Well Points Air Bridges Chain Link Fence & Gates – New Chain Link Fence & Gates – Repair Temporary Pasture Fencing Permanent Access Roads	0 0 0 0 2 0 0 0 0 0 0	Each Each Each Lump Sum Lump Sum Lump Sum Each Each Linear Foot Linear Foot Linear Foot Linear Foot	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$	- - - 000 - - - - - -	\$ - \$ - \$ 10,000 \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ -	
630 630 630 630 630 630 831 832 832 832 832 832 832	Erosion Eel 20" Permanent Waterbar Installation Temporary Waterbar Installation Filtration Sediment Bags 10' x 15' Dewater Structure Clear Water Diversion Pit Stabilized Construction Entrance 20'W x 50'L x 6"D Well Points Air Bridges Chain Link Fence & Gates – New Chain Link Fence & Gates – Repair Temporary Pasture Fencing Permanent Access Roads Temporary Access Roads	0 0 0 0 2 0 0 0 0 0 0 0 0	Each Each Each Lump Sum Lump Sum Lump Sum Each Each Each Linear Foot	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		\$ - \$ - \$ 10,000 \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ -	
630 630 630 630 630 630 831 832 832 832 832 832 832 832	Erosion Eel 20" Permanent Waterbar Installation Temporary Waterbar Installation Filtration Sediment Bags 10' x 15' Dewater Structure Clear Water Diversion Pit Stabilized Construction Entrance 20'W x 50'L x 6"D Well Points Air Bridges Chain Link Fence & Gates – New Chain Link Fence & Gates – Repair Temporary Pasture Fencing Permanent Access Roads Temporary Access Roads Top Soil	0 0 0 0 2 0 0 0 0 0 0 0 0 0 0 0	Each Each Each Lump Sum Lump Sum Lump Sum Each Each Linear Foot	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		\$ - \$ - \$ 10,000 \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ -	
630 630 630 630 630 630 831 832 832 832 832 832 832 832 832 832	Erosion Eel 20" Permanent Waterbar Installation Temporary Waterbar Installation Filtration Sediment Bags 10' x 15' Dewater Structure Clear Water Diversion Pit Stabilized Construction Entrance 20'W x 50'L x 6"D Well Points Air Bridges Chain Link Fence & Gates – New Chain Link Fence & Gates - Repair Temporary Pasture Fencing Permanent Access Roads Temporary Access Roads Top Soil Asphalt Removal/Restoration	0 0 0 0 2 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Each Each Each Lump Sum Lump Sum Lump Sum Each Each Linear Foot Linear Foot Linear Foot Linear Foot Linear Foot Linear Foot Square Foot	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		\$ - \$ - \$ 10,000 \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ -	
630 630 630 630 630 630 630 831 832 832 832 832 832 832 832 832 832 832	Erosion Eel 20" Permanent Waterbar Installation Temporary Waterbar Installation Filtration Sediment Bags 10' x 15' Dewater Structure Clear Water Diversion Pit Stabilized Construction Entrance 20'W x 50'L x 6"D Well Points Air Bridges Chain Link Fence & Gates – New Chain Link Fence & Gates - Repair Temporary Pasture Fencing Permanent Access Roads Top Soil Asphalt Removal/Restoration Sheet Piling	0 0 0 0 2 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Each Each Each Lump Sum Lump Sum Lump Sum Each Each Linear Foot Lonear Foot Day	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		\$ - \$ - \$ 10,000 \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ -	
630 630 630 630 630 630 831 832 832 832 832 832 832 832 832 832	Erosion Eel 20" Permanent Waterbar Installation Temporary Waterbar Installation Filtration Sediment Bags 10' x 15' Dewater Structure Clear Water Diversion Pit Stabilized Construction Entrance 20'W x 50'L x 6"D Well Points Air Bridges Chain Link Fence & Gates – New Chain Link Fence & Gates - Repair Temporary Pasture Fencing Permanent Access Roads Temporary Access Roads Top Soil Asphalt Removal/Restoration	0 0 0 0 2 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Each Each Each Lump Sum Lump Sum Lump Sum Each Each Linear Foot Linear Foot Linear Foot Linear Foot Linear Foot Linear Foot Square Foot	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		\$ - \$ - \$ 10,000 \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ -	
630 630 630 630 630 630 831 832 832 832 832 832 832 832 832 832 832	Erosion Eel 20" Permanent Waterbar Installation Temporary Waterbar Installation Filtration Sediment Bags 10' x 15' Dewater Structure Clear Water Diversion Pit Stabilized Construction Entrance 20'W x 50'L x 6"D Well Points Air Bridges Chain Link Fence & Gates – New Chain Link Fence & Gates – Repair Temporary Pasture Fencing Permanent Access Roads Temporary Access Roads Top Soil Asphalt Removal/Restoration Sheet Piling Ditch Shoring	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Each Each Each Lump Sum Lump Sum Lump Sum Each Each Linear Foot Lonear Foot Day	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		\$ - \$ - \$ 10,000 \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ -	
630 630 630 630 630 630 831 832 832 832 832 832 832 832 832 832 832	Erosion Eel 20" Permanent Waterbar Installation Temporary Waterbar Installation Filtration Sediment Bags 10' x 15' Dewater Structure Clear Water Diversion Pit Stabilized Construction Entrance 20'W x 50'L x 6"D Well Points Air Bridges Chain Link Fence & Gates – New Chain Link Fence & Gates – Repair Temporary Pasture Fencing Permanent Access Roads Temporary Access Roads Top Soil Asphalt Removal/Restoration Sheet Piling Ditch Shoring Road Plates (10' Long)	0 0 0 0 2 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Each Each Each Each Lump Sum Lump Sum Lump Sum Each Each Linear Foot Linear Foot Linear Foot Linear Foot Linear Foot Day Day Each	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		\$ - \$ - \$ 10,000 \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ -	
630 630 630 630 630 630 831 832 832 832 832 832 832 832 832 832 832	Erosion Eel 20" Permanent Waterbar Installation Temporary Waterbar Installation Filtration Sediment Bags 10' x 15' Dewater Structure Clear Water Diversion Pit Stabilized Construction Entrance 20'W x 50'L x 6"D Well Points Air Bridges Chain Link Fence & Gates – New Chain Link Fence & Gates – Repair Temporary Pasture Fencing Permanent Access Roads Temporary Access Roads Top Soil Asphalt Removal/Restoration Sheet Piling Ditch Shoring Road Plates (10' Long) Trench Boxes	0 0 0 0 2 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Each Each Each Each Lump Sum Lump Sum Lump Sum Each Each Each Linear Foot Linear Foot Linear Foot Linear Foot Day Day Each Day Each Day	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		\$ - \$ - \$ 10,000 \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ -	
630 630 630 630 630 630 831 832 832 832 832 832 832 832 832 832 832	Erosion Eel 20" Permanent Waterbar Installation Temporary Waterbar Installation Filtration Sediment Bags 10' x 15' Dewater Structure Clear Water Diversion Pit Stabilized Construction Entrance 20'W x 50'L x 6"D Well Points Air Bridges Chain Link Fence & Gates – New Chain Link Fence & Gates – Repair Temporary Pasture Fencing Permanent Access Roads Temporary Access Roads Top Soil Asphalt Removal/Restoration Sheet Pilling Ditch Shoring Road Plates (10' Long) Trench Boxes Traffic Control (Flaggers)	0 0 0 0 2 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Each Each Each Each Lump Sum Lump Sum Lump Sum Lump Sum Lump Sum Linear Foot Linear Foot Linear Foot Linear Foot Linear Foot Day Day Each Day Day Day	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		\$ - \$ - \$ 10,000 \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ -	
630 630 630 630 630 630 831 832 832 832 832 832 832 832 832 832 832	Erosion Eel 20" Permanent Waterbar Installation Temporary Waterbar Installation Filtration Sediment Bags 10' x 15' Dewater Structure Clear Water Diversion Pit Stabilized Construction Entrance 20'W x 50'L x 6"D Well Points Air Bridges Chain Link Fence & Gates – New Chain Link Fence & Gates – Repair Temporary Pasture Fencing Permanent Access Roads Temporary Access Roads Top Soil Asphalt Removal/Restoration Sheet Piling Ditch Shoring Road Plates (10' Long) Trench Boxes Traffic Control (Flaggers) Traffic Control (Signage)	0 0 0 0 2 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Each Each Each Each Lump Sum Lump Sum Lump Sum Each Each Linear Foot Linear Foot Linear Foot Linear Foot Linear Foot Day Day Day Day Day Day Day Day	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		\$ - \$ - \$ 10,000 \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ -	
630 630 630 630 630 630 831 832 832 832 832 832 832 832 832 832 832	Erosion Eel 20" Permanent Waterbar Installation Temporary Waterbar Installation Filtration Sediment Bags 10' x 15' Dewater Structure Clear Water Diversion Pit Stabilized Construction Entrance 20'W x 50'L x 6"D Well Points Air Bridges Chain Link Fence & Gates – New Chain Link Fence & Gates – Repair Temporary Pasture Fencing Permanent Access Roads Temporary Access Roads Top Soil Asphalt Removal/Restoration Sheet Pilling Ditch Shoring Road Plates (10' Long) Trench Boxes Traffic Control (Flaggers)	0 0 0 0 2 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Each Each Each Each Lump Sum Lump Sum Lump Sum Lump Sum Lump Sum Linear Foot Linear Foot Linear Foot Linear Foot Linear Foot Day Day Each Day Day Day	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		\$ - \$ - \$ 10,000 \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ -	
630 630 630 630 630 630 831 832 832 832 832 832 832 832 832 832 832	Erosion Eel 20" Permanent Waterbar Installation Temporary Waterbar Installation Filtration Sediment Bags 10' x 15' Dewater Structure Clear Water Diversion Pit Stabilized Construction Entrance 20'W x 50'L x 6"D Well Points Air Bridges Chain Link Fence & Gates – New Chain Link Fence & Gates – Repair Temporary Pasture Fencing Permanent Access Roads Temporary Access Roads Top Soil Asphalt Removal/Restoration Sheet Piling Ditch Shoring Road Plates (10' Long) Trench Boxes Traffic Control (Flaggers) Traffic Control (Signage)	0 0 0 0 2 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Each Each Each Each Lump Sum Lump Sum Lump Sum Each Each Linear Foot Linear Foot Linear Foot Linear Foot Linear Foot Day Day Day Day Day Day Day Day	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		\$ - \$ - \$ 10,000 \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ -	
630 630 630 630 630 630 630 831 832 832 832 832 832 832 832 832 832 832	Erosion Eel 20" Permanent Waterbar Installation Temporary Waterbar Installation Filtration Sediment Bags 10' x 15' Dewater Structure Clear Water Diversion Pit Stabilized Construction Entrance 20'W x 50'L x 6"D Well Points Air Bridges Chain Link Fence & Gates – New Chain Link Fence & Gates - Repair Temporary Pasture Fencing Permanent Access Roads Temporary Access Roads Top Soil Asphalt Removal/Restoration Sheet Piling Ditch Shoring Road Plates (10' Long) Trench Boxes Traffic Control (Flaggers) Traffic Control (Signage) Traffic Control (Barriers) Flowable Fill	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Each Each Each Each Lump Sum Lump Sum Lump Sum Each Each Linear Foot Linear Foot Linear Foot Linear Foot Linear Foot Day Day Day Day Day Day Day Day Cubic Yard	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		\$ - \$ - \$ 10,000 \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ -	
630 630 630 630 630 630 630 831 832 832 832 832 832 832 832 832 832 832	Erosion Eel 20" Permanent Waterbar Installation Temporary Waterbar Installation Filtration Sediment Bags 10' x 15' Dewater Structure Clear Water Diversion Pit Stabilized Construction Entrance 20'W x 50'L x 6"D Well Points Air Bridges Chain Link Fence & Gates – New Chain Link Fence & Gates – Repair Temporary Pasture Fencing Permanent Access Roads Top Soil Asphalt Removal/Restoration Sheet Piling Ditch Shoring Road Plates (10' Long) Trench Boxes Traffic Control (Flaggers) Traffic Control (Signage) Traffic Control (Signage) Traffic Control (Barriers) Flowable Fill Noise Reduction Barriers	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Each Each Each Each Lump Sum Lump Sum Lump Sum Each Each Linear Foot Linear Foot Linear Foot Linear Foot Day Day Day Day Day Day Cubic Yard Day	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		\$ - \$ - \$ 10,000 \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ - \$ -	
630 630 630 630 630 630 630 831 832 832 832 832 832 832 832 832 832 832	Erosion Eel 20" Permanent Waterbar Installation Temporary Waterbar Installation Filtration Sediment Bags 10' x 15' Dewater Structure Clear Water Diversion Pit Stabilized Construction Entrance 20'W x 50'L x 6"D Well Points Air Bridges Chain Link Fence & Gates – New Chain Link Fence & Gates – Repair Temporary Pasture Fencing Permanent Access Roads Temporary Access Roads Top Soil Asphalt Removal/Restoration Sheet Piling Ditch Shoring Road Plates (10' Long) Trench Boxes Traffic Control (Flaggers) Traffic Control (Signage) Traffic Control (Barriers) Flowable Fill Noise Reduction Barriers Rectifier/Groundbed (CP)	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Each Each Each Each Lump Sum Lump Sum Lump Sum Each Each Each Linear Foot Linear Foot Linear Foot Linear Foot Day Day Day Day Day Day Cubic Yard Day Each Day Day Each Day Day Each Day Day Day Day Each Day Day Day Day Day	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		\$ - \$ - \$ 10,000 \$ 150,000 \$ 150,000 \$ 10,000 \$ \$ 10,000 \$ \$ 10,000 \$ \$ \$ \$ \$ \$ \$ \$ \$	
630 630 630 630 630 630 630 831 832 832 832 832 832 832 832 832 832 832	Erosion Eel 20" Permanent Waterbar Installation Temporary Waterbar Installation Filtration Sediment Bags 10' x 15' Dewater Structure Clear Water Diversion Pit Stabilized Construction Entrance 20'W x 50'L x 6"D Well Points Air Bridges Chain Link Fence & Gates – New Chain Link Fence & Gates – Repair Temporary Pasture Fencing Permanent Access Roads Top Soil Asphalt Removal/Restoration Sheet Piling Ditch Shoring Road Plates (10' Long) Trench Boxes Traffic Control (Flaggers) Traffic Control (Signage) Traffic Control (Signage) Traffic Control (Barriers) Flowable Fill Noise Reduction Barriers	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Each Each Each Each Lump Sum Lump Sum Lump Sum Each Each Linear Foot Linear Foot Linear Foot Linear Foot Day Day Day Day Day Day Cubic Yard Day	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		\$ - \$ - \$ 10,000 \$ 5 5 5 5 5 5 5 5 5	

								в
	SCADA for MLV Sites	0	Each	\$	100,000		-	
	Electrical/Controls for MLV Sites	0	Each	\$	50,000	\$	-	
	Security for MLV Sites	0	Each	\$	21,000	\$	-	
	L/R Installation	0	Each	\$	-	\$	-	
	Painting & Waxing Flanges	0	Lump Sum	\$	25,000	\$	-	
	Staging & Laydown Yard	0	Acre	\$	65,000	\$	-	
	Railway Crossings	0	Each	\$	20,000	\$	-	
	Temp LNG Skids	3	Lump Sum	\$	1,500,000	\$	4,500,000	
	Contractor Tap Support	4	Each	\$	68,470	\$	273,880	
	TDW - Hot Tap	0	Each	\$	-	\$	-	
	TDW - Tap & Stop	4	Each	\$	74,100	\$	296,400	
	TDW - Bypass	0	Each	\$	-	\$	-	
	HDD Mudd Disposal	0	Linear Foot	\$	-	\$	-	
	HDD Mudd Engineer	0	Per HDD	\$	20,000	\$	-	
ub-Total - Co	onstruction Services - Pipeline							\$ 9,970,500
ield Inspectio	on & Testing							
G880	Construction Inspection	712	Man-Days	\$	840		598,230	
G881	Non-Destructive Testing	5	Days	\$	2,000	\$	9,971	
ıb-Total - Fie	eld Inspection & Testing							\$ 608,300
lajor Equipm	nent & Materials							
	Pipe							
G205	24" Standard Wall, X52, Coated, DRL	40	Linear Foot	\$	208	\$	8,320	
G205	XX" Standard Wall, X52, Powercrete	0	Linear Foot	\$	-	\$	-	
G205	XX" Standard Wall, X52, Bare	0	Linear Foot	\$	-	\$	-	
	Fittings							
G205	XX" 3R - 45 deg ell - Segmentable	0	Each	\$	-	\$	-	
G205	XX" 3R - 90 deg ell - Segmentable	0	Each	\$	-	_	-	
	Equipment							
G204	24" TDW Stopple	4	Each	\$	44,300	\$	177,200	
G204	XX" TDW Spherical Tee	0	Each	\$			- ,	
G204	XX" L/R Module	0	Each	\$	-	\$	-	
G204	XX" MLV Module	0	Each	\$	-	_	-	
	Miscellaneous							
	Rectifier/Groundbed Material (CP)	4	Each	\$	2,500	\$	10,000	
	AC Mitigation Material	0	Each	\$	45,000	_	-	
G204	SCAR Guard	0	Linear Foot	\$		\$	-	
G205	Misc. Materials (10% of Total Major)	1	Calculated	\$	19,552		19,552	
G205	Taxes & Freight (9% of All Material)	1	Calculated	\$		\$	19,356	
ub-Total - M				1		7		\$ 234,500
ub-Total								\$ 11,263,80
calation								\$ 11,203,800
ontingency								\$ 1,689,600
	Total Table							
ripeline Est	imate Total							\$ 12,953,400

	Line AM0	7 Re-Hy	dro						
	Reti	rement					Revision #	Α	
Control Code	Component Description	Units	Unit of Measure		Jnit Cost		Sub-totals		Totals
Internal Engineeri	ng & Construction Management								
G101	PNG Labor	40	Month	\$	1,600		64,000		
OTH001	Other Direct Cost	40	Month	\$	400	\$	16,000		
Sub-Total - Intern	al E&CM							\$	80,000
External Engineer	ing								
G810	Design - Pipeline	64	Hour	\$	125	\$	8,025		
G811	Design - Facility	0	Hour	\$	125	\$	-		
G663	MAOP	1	Lump Sum	\$		\$	-		
Sub-Total - Extern	nal Engineering							\$	8,100
Land Camiasa									
Land Services	Transmission Town World Conner Dural		A = = =	Ċ	45,000	ć			
G-663 G-663	Transmission - Temp Work Space - Rural Transmission - Temp Work Space - Urban	0	Acre	\$	5,000	_	-		
	Transmission - Temp Work Space - Orban Transmission - Access Roads	0	Acre Each	\$	10,000	_			
G-662 PA/G-663 17 G-301	Contract Labor - Land Services	0	Per Parcel	\$	10,000				
Sub-Total - Land S		U	Per Parcer	Ş	10,000	Ş	-	Ś	
Jub-Total - Land 3	ei vices							٠	
Construction Serv	ices - Pipeline	0	Overall LF of P	ipe t	be Aband	one	d		
850	Mob/Demob	1	Lump Sum	\$	3,770	\$	3,770		
	Demo Equipment	0	Days	\$	7,500	\$	-		
823	Grouting of Abandoned Pipe	0	Cubic Yard	\$	-	\$	-		
824	Removal of Existing Pipeline	20	Linear Foot	\$	260	\$	5,200		
	Tar Coated Steel Remediation & Removal	0	LF	\$	-	\$	-		
	Install & Remove Flare + Mob/Demob	0	Lump Sum	\$	50,000	\$	-		
G863	Launcher/Receiver Removal	0	Each	\$	75,000	\$	-		
G863	Small Station Removal	0	Each	\$		\$	-		
G863	Medium Station Removal	0	Each	\$	50,000	\$	-		
G863	Large Station Removal	0	Each	\$	85,000	_	-		
	Haul Materials	2	Lump Sum	\$	10,000	_	20,000		
	Nitrogen Clearing	0	Lump Sum	\$	50,000		-		
	Line Locating	1	Week	\$	12,500	\$	12,500		
	Contractor Tap Support	0	Days	\$	-	\$	-		
	Seeding	0	SF	\$	-	\$	-		
	Clean up	0	LF	\$	-	\$	=		
	TDW Tap	0	Each	\$	-	\$	-		
								\$	41,500
Field Inspection &	Testing								
G880	Construction Inspection	7	Man-Days	\$	840	Ś	6,225		
G881	Non-Destructive Testing	0	Days	\$	2,000		-		
Sub-Total - Field I	nspection & Testing		, ,					\$	6,300
								_	
Major Equipment		2	Lucian Const	Ċ	F 000	ć	10.000		
G205	Purge Materials	2	Lump Sum	\$	5,000		10,000		
G204	Stopple	0	Each	\$		\$	-		
G204	Stopple Miss Matarials (100/ of Tatal Major)	0	Each	\$		\$	1 000		
G205 G205	Misc. Materials (10% of Total Major) Taxes & Freight (9% of All Material)	1	Calculated Calculated	\$	1,000 990		1,000 990		
Sub-Total - Mater	5 1	1	Calculated	Ş	990	٦	990	\$	12,000
Sub-Total - Mater	idis —								
								\$	147,900
Escalation								\$	22,200
Contingency	to Tabel							\$	
Pipeline Estima	te rotal							\$	170,100