

# LOOP CUTOVER PROCESS

Step 1: Technician gets call to begin cutover. Asks for cable pair information.



**KPSC Case No. 2003-00379**  
**Exhibit: MDV-8**

## **LOOP CUTOVER PROCESS**

Step 2: Technician types in cable pair number to obtain order number.





## **LOOP CUTOVER PROCESS**

Step 3: Technician retrieves copy of work order.



## **LOOP CUTOVER PROCESS**

Step 4: Technician responds to UNE Center request to initiate overall cutover of service from BellSouth to CLEC.





## **LOOP CUTOVER PROCESS**

Step 5: Technician conducts ANAC test to verify that correct loop is being cutover.



## **LOOP CUTOVER PROCESS**

Step 6: Technician walks along Main Distributing Frame to locate both ends of jumper to be cut.






# LOOP CUTOVER PROCESS

Step 7: Technician locates precise location of jumper.



## **LOOP CUTOVER PROCESS**


Step 8: Technician locates and removes end of jumper connected to the BellSouth cable pair.






## **LOOP CUTOVER PROCESS**

Step 9: Technician locates and removes end of jumper connected to the switching equipment.



## LOOP CUTOVER PROCESS


Step 10: Technician places new jumper on MDF.





## LOOP CUTOVER PROCESS

Step 11: Technician weaves wire through cable rack to reach tie cable to CLEC's collocation equipment.



## **LOOP CUTOVER PROCESS**

Step 12: Technician connects new jumper on frame to tie cables to CLEC equipment.





## **LOOP CUTOVER PROCESS**

Step 13: Technician conducts ANAC test to verify that loop has been cut to correct CLEC switch port.



## **LOOP CUTOVER PROCESS**

Step 14: Technician verifies cutover with CLEC, closes order, and notifies the UNE Center.

